JUNIOR GLENDALE

Wall Mount Hinge - Factory Set 5 Degree Positive Close Offset Back Plate ITEM NO. JRGLEN05

SPECIFICATIONS

Glass Sizes: 1/4" (6 mm) Tempered Glass Only Construction: Solid Brass Cutout Required: See Page 2 Closing Type: Self-Centering When Within 15 Degrees of Closed Position Includes: Hinge body, glazing gaskets, wall mounting screws, allen head/phillips head cover plate screws, and fabrication template. Use: Residential Bath and Commercial Hotel Applications



For 1/4" (6 mm) Glass: Use One Thick Gasket On Each Side


GLASS INSTRUCTIONS:


Only use tempered safety glass. To prevent damage to the hinge finish during installation, <u>do not</u> use power tools when installing these hinges.

IMPORTANT INFORMATION:

The Junior Glendale Series Hinge comes factory set to allow an additional 5 degrees of closing for jobs that require a firmer positive position against a jamb or seal.

MAXIMUM DOOR CAPACITY	1/ 4" (6 mm) GLASS Approx. 3 lb/ft ²	
	DOOR WEIGHT	DOOR WIDTH
USING 2 HINGES	55 LBS. (25 kg)	32" (813 mm)
USING 3 HINGES	85 LBS. (38.6 kg)	36" (914 mm)
NOTE: Do not exceed either maximum weight or width when choosing proper quantity of hinges.		





EE TEMPLATE ON BACK Refer to Dimensions Shown Densure Accuracy

CARE & CLEANING GUIDELINES:

For best results, keep the following recommendations in mind when caring for your FHC shower door hardware. Your shower door should be dried daily with a soft towel or cloth to ensure its original finish. Do not use harsh cleaners or chemicals on the hardware, as many of the components are coated with a clear lacquer that will become damaged beyond repair. Always test your cleaning solution in an inconspicuous area prior to cleaning the entire hardware surface. Wipe surfaces clean using a soft, dampened cloth or sponge, and rinse completely with warm water immediately after applying the cleaning solution. Use only small amounts of liquid, gentle, cleaner. <u>Never</u> use abrasive products, sponges, or wire scrub brushes while cleaning hardware.

MAINTENANCE:

FHC's hinges come factory greased for a silent, hassle-free experience. If there is any noticeable squeaking that occurs after installation it is recommended to apply a few drops of (3 in 1) multi-purpose oil to the hinge, at the nylon washer/pivot location. The lubricant will penetrate the hinge crevices, reducing friction, cleaning grime, and/or buildup. Spray lubricants are prohibited. If, for some reason, the hinge is disassembled during maintenance, use a small amount of white lithium grease to lubricate the interior hinge components.




FRAMELESS HARDWARE COMPANY

P.O. Box 1906, South Gate, CA 90280 Toll Free: (888) 295-4531 | Fax: (323) 336-8307 | Web: fhc-usa.com

JUNIOR GLENDALE

Wall Mount Hinge - Factory Set5 Degree Positive Close Offset Back PlateITEM NO. JRGLEN05





USE DIMENSIONS SHOWN

IF.







For Technical Support Call Toll Free in the U.S. (888) 295-4531



