

## Edge Operation:

Press contacts firmly against glass. The edge of the glass should rest against the stop of the enclosure. The indicator illuminates if contacts touch conductive (Low-E) coating.



---

## Center of Glass Operation:

Press contacts firmly against glass by tilting detector on an angle. The indicator illuminates if contacts touch conductive (Low-E) coating.



---

## To replace battery:

Use a paper clip to push battery out. Grasp and slide battery straight out.

Replace with a new CR2016 battery. Align positive “+” side of battery with the “+” indication on enclosure.

