

STEP 1

Clean glass surface using Surface Prep (50% isopropyl alcohol/50% filtered water) and a soft cloth. Finish by drying surface completely.

STEP 2

Apply a small amount of Liquid Diamonds treatment to a clean applicator pad and wipe surface immediately with pad making sure that the product is evenly dispersed over the surface. (One ounce will cover approximately 50-60 Sq. Ft.). Allow Liquid Diamonds to remain on the surface for 2 minutes.

STEP 3

Remove residual Liquid Diamonds by using a clean Micro Fiber Cloth and a mist of Diamond Blue wash and buff to a shine.