

What electric strike does your access control project need?

## Electric strikes can be installed in a wide range of swinging door applications.

Consider these factors to help determine the right electric strike for your project.

### 1. Assess the type of frame and health of the opening

- a. **Material:** hollow metal, aluminum or wood?

*\*Adams Rite offers electric strikes specifically for aluminum, hollow metal or wood doors. Please see the Adams Rite catalog to order the compatible model for your door application.*

- b. **Type:** hollow or concrete-filled? Concrete-filled may require additional tools. Consider using no-cut electric strikes.

- c. **Health of door and frame:** can frame or door irregularities be fixed prior to electric strike installation?

### 2. Determine if door assembly has special requirements


- Fire-rated Assembly (NFPA 80 Fire Doors)
- Windstorm Resistant (tested to sustain winds up to 150 mph)
- Outdoor Rated (UL 1034)
- Preload Capable

### 3. Identify and test existing door hardware

- Existing locking hardware determines the compatible electric strike and overall function of the opening
- Make sure existing hardware works properly and is not broken or damaged



## Most Common Accessories



### HESCUT-MTK

Metal Template Kit for installing cut-in HES electric strikes

For installing the ES100, 1006, 1500, 1600, 5000, 5200, 5300, 7000 and 7501 electric strikes.

### 9000 MTK


Metal Template Kit for installing HES surface mounted electric strikes

For installing the 9400, 9500, 9600, 9700 and 9800 electric strikes.

### 2005M3 Smart Pac® III


Reduces initial voltage in timed or fail safe operations by 25% to extend the life of the electric strike.

Select the right power supply for your project with Securitron AQ Series Power Supplies



### Cylindrical up to 3/4" Latchbolt

HES ES100			
HES 1006, 1500, 1600			
HES 5200			
HES 7000			
HES 7501			
Adams Rite 7100 Series			
Adams Rite Ultraline® 7400 Series			
Securitron UNL			



### Cylindrical with 1/2", 5/8" Latchbolt

NEW

HES 5000			
HES 5300			
HES 8000			
HES 8300			



### Mortise Lockset without a Deadbolt up to 3/4" Throw Latchbolt

HES ES100-15				HES 1006, 1500, 1600			
HES 8500				Adams Rite 7160			
Securitron MUNL				HES ES100-16			



### Mortise Lockset with a 1" Deadbolt

HES ES100-16				HES 1006, 1500, 1600			
--------------	--	--	--	----------------------	--	--	--

NEW

### Tubular Vertical Rod Exit Devices

HES 9100 Single Doors							
HES 9200 Double Doors							



### Rim Exit Devices up to 1/2" Throw Latchbolt

HES 9400				Adams Rite Ultraline® 74R2	
----------	--	--	--	----------------------------	--



### Rim Exit Devices up to 3/4" Pullman Latchbolt

HES 7000		The 7000 works with Rim Exit Devices only when paired with 783S, 786S, 789S Faceplates.				
HES 9500						
HES 9600						
Adams Rite Ultraline® 74R1						



### Rim Exit Devices with Corbin Russwin SecureBolt® or Yale SquareBolt®

HES 9700					
----------	--	--	--	--	--



### Rim Exit Devices with Adams Rite Starwheel or Interlocking Latchbolt

HES 9800			
----------	--	--	--

## ASSA ABLOY

Opening Solutions

ADAMS RITE | adamsrite.com  
HES | hesinnovations.com  
SECURITRON | securitron.com  
800 872 3267

Patent pending and/or patent www.assaabloydss.com/patents

Copyright © 2023 Hanchett Entry Systems, Inc., an ASSA ABLOY Group company. All rights reserved. Reproduction in whole or in part without the express written permission of Hanchett Entry Systems, Inc. is prohibited. EMS-21-1223